

**maier® GUARANTEE OF MHI-302**


※ Article	Aromadrive	Date of Purchase	Period of Guarantee
		DMY	One year from the date of purchase
※ Customer	Name		
	Address & Phone		
※ Store	Name of the store & its Add		

- 1) This product passes the strict tests prior to leaving factory. Customers could within one year from the date of purchase, enjoy free repair or replacement of parts against presentation of this guarantee if it is attested by our company that malfunction or damage to the device and/or parts occurs under normal running condition.
- 2) The guarantee does not cover the damages that are attributable to self dismantling and assembling, unauthorized operation not found in the instruction, random change of power source and/or voltage artificial causes and natural disaster.
- 3) Date(s) on this guarantee and the purchase invoice is the evidence of one year free maintenance.

Car Air Purifier With  
Aromatherapy Essence

# Aromadrive

## Instruction Manual



### How to use & place the Air Purifier

- **Place the MHI-302 centrally on the front part of the car.**  
The two "Velcro" pads inside the box sticks the negative ion air purifier into position. This will allow the driver to breathe the fresh, clean air and stay alert. With its ventilation system, fresh air will circulates in the vehicle immediately.
- **Plug in on the cigarette lighter adaptor when used in vehicle.**  
Plug one end of wire into the cigarette lighter socket and connect the other end to the unit. Turn on the power switch and the LED will light indicates that the unit is operating normally. You will smell the fresh and fragrant air at the same time.
- **Refill the fragrance holder.**  
A fragrance holder is located in the bottom of the unit. Unscrew and refill with a fragrance of your choice.

### Technical Specifications

Model	Rated voltage	Power consumption	Ion output	Active oxygen output	Dimensions (mm)	Weight
MHI-302	DC 12V	3W	MAX 10,000/cm <sup>3</sup>	≤0.04ppm	140×90×50	180g or 0.4lbs

### Cleaning and Maintenance

- **Unplug.**  
Unplug the MHI-302 before performing any maintenance.
- **Unscrew & perform cleaning.**  
Turn the MHI-302 upside down and place it on a towel. Loosen the screws and carefully clean the dust with soft dry cloth or q-tip.
- **Clean once a month.**  
Perform maintenance when needed or at least once every 3 months to keep your MHI-302 operating at peak performance.

#### Function Indication Figure



Fragrance holder (at the bottom)

